

Voice Guidance

Administrator's Guide

June 2015

www.lexmark.com

Contents

| Overview | | |
|---|----|--|
| Supported printer models, functions, and applications | 3 | |
| Configuring Voice Guidance | 4 | |
| Activating Voice Guidance | | |
| Adjusting Voice Guidance speech rate | 4 | |
| Setting the default headphone volume | | |
| Adjusting headphone and internal speaker volume | 4 | |
| Changing the language on the printer display | 5 | |
| Understanding prolonged screen timeout | 5 | |
| Deactivating Voice Guidance | 5 | |
| Using voice guidance and the keyboard | 6 | |
| Using the keyboard | 6 | |
| Performing basic printer functions | 7 | |
| Notices | 9 | |
| Index | 10 | |

Overview

Use Lexmark Voice Guidance to provide audio feedback while you navigate through the printer display. A green rectangle (focus cursor) surrounds the icons and buttons, providing a visual cue for navigation. Voice Guidance lets you perform basic printer tasks and access supported applications.

Supported printer models, functions, and applications

| Models | Functions | Applications* |
|---|-----------------|---|
| MX910 Series | Сору | Print Release |
| MX810 Series | Fax | Scan to Network Basic |
| MX710 Series | E-mail | Secure Held Print Jobs |
| MX610 Series | FTP | Smart Card Authentication Client bundle |
| MS812de | Scan | |
| CX510 | Held Jobs | |
| | USB | |
| | Status/Supplies | |
| | Job Cancel | |
| * Availability of the updated version of the applications may vary. | | |

Configuring Voice Guidance

Notes:

- Lexmark Voice Guidance is compatible with Lexmark Accessibility Solution.
- Update the printer with the latest firmware before using Voice Guidance.

Activating Voice Guidance

Notes:

- Before activating Voice Guidance, make sure that Lexmark Accessibility Speech Solution is deactivated.
- Before launching a supported eSF application, activate Voice Guidance.
- 1 From the printer keypad, press and hold the 5 key until the Accessibility Modes screen appears.

Note: This key has one tactile bump for easy recognition.

- 2 From the keyboard, press **Tab** to move the focus cursor to 🥙.
- 3 Press Enter.

To activate using the headphones, plug the headphone jack into the audio port of the kit.

Adjusting Voice Guidance speech rate

- **1** From the home screen, touch **E** > **Settings** > **General Settings** > **Accessibility** > **Speech Rate**.
- 2 Select a setting.
- **3** Apply the changes.

Note: This setting remains after power-on reset or when the printer wakes from Sleep mode.

Setting the default headphone volume

- **1** From the home screen, touch **E** > **Settings** > **General Settings** > **Accessibility**.
- **2** From the Headphone Volume field, set the default volume.
- **3** Apply the changes.

Note: This setting remains after power-on reset or when the printer wakes from Sleep mode.

Adjusting headphone and internal speaker volume

Note: These settings can only be adjusted on the home screen and can be controlled independently.

- From the keyboard, press Backspace several times to set the volume level that you want.
- From the printer keypad, press the back button several times to set the volume level that you want.

Changing the language on the printer display

- **1** From the home screen, touch **B** > **Settings** > **General Settings**.
- 2 From the Display Language field, select the language.
- 3 Apply the changes.

Note: Voice Guidance supports only English, French, German, Italian, and Spanish languages. This mode follows the selected language setting and is deactivated for unsupported languages.

Understanding prolonged screen timeout

Screen timeout setting is ignored whenVoice Guidance is activated. The following shows the screen timeout behavior during Voice Guidance mode:

- Screen timeout is extended automatically by a factor of 10.
- Prompts to extend timeout no longer appears.

The standard prolonged screen timeout setting is followed when Voice Guidance is deactivated.

Deactivating Voice Guidance

1 From the printer keypad, press and hold the 5 key until the Accessibility Modes screen appears.

Note: This key has one tactile bump for easy recognition.

- 2 Press Enter.
- **3** Press **Tab** to move the focus cursor to
- 4 Press Enter.

The printer exits Voice Guidance mode when you perform a power-on reset, or when the printer wakes from Sleep or Hibernate mode. Voice Guidance is also deactivated when headphones are removed, session is logged out, or panel login timeout expires.

Using voice guidance and the keyboard

Using the keyboard

Keyboard navigation functions independently or in tandem with Voice Guidance. While most USB keyboard will work with keyboard navigation function, operation is only supported with the keyboard from Lexmark.

To enable keyboard navigation on supported devices, plug a USB keyboard into the USB port on the rear of the printer. For Voice Guidance navigation, plug the keyboard into the Voice Guidance control box.

Understanding the keyboard functions

Use the keyboard to navigate and select menu options, with the current focus item surrounded by the focus cursor. Where possible, key function mirrors that of assistive technologies, such as screen readers.

Notes:

- Keyboard navigation is compatible with Lexmark Voice Guidance, Lexmark Accessibility Solution, and Lexmark Accessibility Speech.
- Make sure that the printer is updated with the latest firmware. For more information, contact your administrator.

| Use | То | |
|---|---|--|
| Tab | Go to the next setting. | |
| Tab + Shift | Go back to the previous setting. | |
| Enter | Initiate action. Select setting values. Open a menu. Accept a selection. | |
| Up arrow | Go back to the previous item within a list. | |
| Down arrow | Go to the next item within a list. | |
| Left arrow | Select a lower value. | |
| Right arrow | Select a higher value. | |
| Home | Exit application and return to the home screen. | |
| Esc | Cancel a job.Go back to the previous setting.Exit a pop-up screen or a setting. | |
| Page down | Jump to the last item of a list. | |
| Page up | Jump to the first item of a list. | |
| Backspace* | Lower the printer speaker volume. | |
| * This key is used only when Voice Guidance is activated. | | |

| Use | То |
|-----------------------|--|
| Pause/Break* | Pause or continue audio message. |
| | Repeat the last spoken message when no audio is playing. |
| * This key is used on | ly when Voice Guidance is activated. |

Changing keyboard type

When using a non-English external keyboard, change the keyboard type to record key presses accurately.

- **1** From the home screen, touch **E** > **Settings** > **General Settings** > **Keyboard**.
- 2 Select the keyboard type.
- **3** Apply the changes.

Performing basic printer functions

Making copies

- **1** Load an original document into the ADF tray or on the scanner glass.
- 2 From the keyboard, press Tab to move the focus cursor to the Copy icon.
- 3 Press Enter.
- 4 Press Tab to move the focus cursor to the Number of Copies field.

Note: To select the number of copies, use the left and right arrow keys.

- **5** Press **Tab** to move the focus cursor to the Copy It button.
- 6 Press Enter.

Sending a fax

- **1** Load the original document into the ADF tray or on the scanner glass.
- 2 From the keyboard, press Tab to move the focus cursor to the Fax icon.
- 3 Press Enter.
- **4** Fill in the required fields.
- 5 Press Tab to move the focus cursor to the Fax It button.
- 6 Press Enter.

Sending an e-mail

- **1** Load an original document into the ADF tray or on the scanner glass.
- 2 From the keyboard, press Tab to move the focus cursor to the E-mail icon.

3 Press Enter.

- **4** Fill in the required fields.
- **5** Press **Tab** to move the focus cursor to the Send It button.
- 6 Press Enter.

Scanning to an FTP server

- **1** Load an original document into the ADF tray or on the scanner glass.
- 2 From the keyboard, press **Tab** to move the focus cursor to the FTP icon.
- 3 Press Enter.
- **4** Fill in the required fields.
- **5** Press **Tab** to move the focus cursor to the Send It button.
- 6 Press Enter.

Notices

June 2015

The following paragraph does not apply to any country where such provisions are inconsistent with local law: LEXMARK INTERNATIONAL, INC., PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user's responsibility.

For Lexmark technical support, visit http://support.lexmark.com.

For information on supplies and downloads, visit www.lexmark.com.

© 2015 Lexmark International, Inc.

All rights reserved.

GOVERNMENT END USERS

The Software Program and any related documentation are "Commercial Items," as that term is defined in 48 C.F.R. 2.101, "Computer Software" and "Commercial Computer Software Documentation," as such terms are used in 48 C.F.R. 12.212 or 48 C.F.R. 227.7202, as applicable. Consistent with 48 C.F.R. 12.212 or 48 C.F.R. 227.7202-1 through 227.7207-4, as applicable, the Commercial Computer Software and Commercial Software Documentation are licensed to the U.S. Government end users (a) only as Commercial Items and (b) with only those rights as are granted to all other end users pursuant to the terms and conditions herein.

Trademarks

Lexmark and the Lexmark logo are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

All other trademarks are the property of their respective owners.

Index

Α

adjusting headphone volume 4 adjusting internal speaker volume 4 adjusting Voice Guidance speech rate 4 applications supported 3

С

changing keyboard type 7 changing printer language 5

D

deactivating voice guidance 5

F

fax sending 7 functions supported 3

Η

headphone volume adjusting 4

I

internal speaker adjusting 4

Κ

keyboard navigation 6 keyboard type changing 7

Μ

making copies 7

Ν

navigation keyboard 6 notices 9

0

overview 3

Ρ

printer language changing 5 printer models supported 3 prolonged screen timeout understanding 5

S

scanning to an FTP server 8 scanning to an FTP server 8 sending e-mail 7 sending an e-mail 7 sending fax 7 speech rate adjusting 4

U

understanding prolonged screen timeout 5 using the ADF copying 7 using the scanner glass copying 7

V

voice guidance deactivating 5 Voice Guidance speech rate adjusting 4 volume headphone, adjusting volume 4